










# Installation Guide

This document provides direct access to the essential installation and wiring resources for Genius Hub products. It includes links to detailed setup instructions, technical documents, and support tools to assist with installation and troubleshooting.

Additional resources include the Full User Guide, Full Installation Guide, Support Knowledge Base, Technical Wiring Documentation, One-to-One Support Booking, Ticket Raising System, and Service Status Updates. All links direct users to the official Genius Hub support pages for easy navigation.

Product Image	Product Name	Installation / Wiring Diagrams	Video Available
	Genius Hub (HUB-D)	<ul style="list-style-type: none"><li><a href="https://geniushub.co.uk/install-hub">geniushub.co.uk/install-hub</a></li><li><a href="https://youtu.be/53oIDpgF3aE">youtu.be/53oIDpgF3aE</a></li></ul>	
	Electric Switch (ESW-D)	<ul style="list-style-type: none"><li><a href="https://geniushub.co.uk/install-esw">geniushub.co.uk/install-esw</a></li><li><a href="https://geniushub.co.uk/wiring">geniushub.co.uk/wiring</a></li><li><a href="https://youtu.be/Mf2OQRaPAMg">youtu.be/Mf2OQRaPAMg</a></li></ul>	
	Wireless Room Thermostat (WRT-D)	<ul style="list-style-type: none"><li><a href="https://geniushub.co.uk/install-wrt">geniushub.co.uk/install-wrt</a></li></ul>	
	Powered Room Thermostat (PRT-A)	<ul style="list-style-type: none"><li><a href="https://geniushub.co.uk/install-prt">geniushub.co.uk/install-prt</a></li><li><a href="https://geniushub.co.uk/wiring">geniushub.co.uk/wiring</a></li></ul>	
	Smart Plug - Dual Band (PLG-E)	<ul style="list-style-type: none"><li><a href="https://geniushub.co.uk/install-plg">geniushub.co.uk/install-plg</a></li></ul>	
	Electric Relay (ERS-A)	<ul style="list-style-type: none"><li><a href="https://geniushub.co.uk/install-ers">geniushub.co.uk/install-ers</a></li><li><a href="https://geniushub.co.uk/wiring">geniushub.co.uk/wiring</a></li></ul>	
	Wireless Radiator Valve (WRV-E)	<ul style="list-style-type: none"><li><a href="https://geniushub.co.uk/install-wrv">geniushub.co.uk/install-wrv</a></li><li><a href="https://youtu.be/JYTkPiJtEoc">youtu.be/JYTkPiJtEoc</a></li></ul>	
	Wireless Room Sensor (WRS-B)	<ul style="list-style-type: none"><li><a href="https://geniushub.co.uk/install-wrs">geniushub.co.uk/install-wrs</a></li><li><a href="https://youtu.be/cM-p31lVEcM">youtu.be/cM-p31lVEcM</a></li></ul>	
	Wireless Motion Sensor (WMS-A)	<ul style="list-style-type: none"><li><a href="https://geniushub.co.uk/install-wms">geniushub.co.uk/install-wms</a></li><li><a href="https://youtu.be/Fy1po9BZVA">youtu.be/Fy1po9BZVA</a></li></ul>	

## Other Links:

Full User Guide:  
[geniushub.co.uk/user-guide](https://geniushub.co.uk/user-guide)

Full Installation Guide:  
[geniushub.co.uk/install-guide](https://geniushub.co.uk/install-guide)

Genius Hub Support Knowledge Base:  
[geniushub.co.uk/knowledge-base](https://geniushub.co.uk/knowledge-base)

One-2-One Support:  
[geniushub.co.uk/shop/support-one2one](https://geniushub.co.uk/shop/support-one2one)

Raise a Ticket:  
[geniushub.co.uk/shop/support-ticket](https://geniushub.co.uk/shop/support-ticket)

Service Status:  
[geniushub.co.uk/service-status](https://geniushub.co.uk/service-status)

Technical Documentation:  
[geniushub.co.uk/wiring](https://geniushub.co.uk/wiring)