




## **Dual Channel Receiver - Combination Boiler (230v)**



## **Internal Diagram**





**PLEASE NOTE:** The boiler controller is mains powered and requires either a separate 3A fused spur orconnection directly into the boiler if the boiler is powered from a 3A fused spur.

**TIP:** Take a photo of the existing wiring before you start to help you remember

**Boiler Terminal** 

**Genius Hub Terminal** 

