



Internal Diagram



Genius Hub Terminal	Boiler Terminal
N	N
L	L
1	Not Connected
2	L Supply
3	Not Connected
4	L Return



PLEASE NOTE: The boiler controller is mains powered and requires either a separate 3A fused spur or connection directly into the boiler if the boiler is powered from a 3A fused spur.