


| Genius Hub Terminal | Boiler Terminal |
|---------------------|-----------------|
| N                   | 2               |
| L                   | 1               |
| 1                   | Not Connected   |
| 2                   | Link from L     |
| 3                   | Not Connected   |
| 4                   | 5               |



**PLEASE NOTE:** The boiler controller is mains powered and requires either a separate 3A fused spur or connection directly into the boiler if the boiler is powered from a 3A fused spur.