



Electric Switch



Single Channel Receiver




NOTE: The Receiver Units are mains powered and require either a separate 3A fused spur or connection directly into the boiler if the boiler is powered from a 3A fused spur.





For more wiring diagrams see:
www.geniushub.co.uk/wiring







Internal Wiring Diagram



Single Channel Receiver



Electric Switch



Electric Relay



WARNING

TO PREVENT RISK OF DAMAGE OR SAFETY HAZARDS, THIS EQUIPMENT SHOULD BE ONLY INSTALLED BY QUALIFIED OR COMPETENT PERSONS AND IN ACCORDANCE WITH ALL APPLICABLE ELECTRICAL REGULATIONS